

PORT OF TORRE ANNUNZIATA

ANCHORING AT ROADS REGULATIONS

Ord. 02/01 01/02/2001

In the roads of Torre Annunziata have been localized the following anchoring zones:

Zone **ALFA**

A1	40° 43'.65 N	014° 26'.00 E
A2	40° 44'.08 N	014° 25'.70 E
A3	40° 44'.09 N	014° 27'.11 E
A4	40° 43'.65 N	014° 27'.00 E

Zone **BRAVO**

B1	40° 44'.08 N	014° 25'.70 E
B2	40° 44'.36 N	014° 25'.53 E
B3	40° 44'.73 N	014° 25'.53 E
B4	40° 44'.90 N	014° 26'.23 E
B5	40° 44'.09 N	014° 26'.07 E

Zone **CHARLIE**

C1	40° 44'.90 N	014° 26'.23 E
C2	40° 44'.09 N	014° 26'.07 E
C3	40° 44'.09 N	014° 27'.11 E
C4	40° 44'.47 N	014° 27'.16 E

In the aforementioned zones have been localized the following anchoring positions:

Vessels/cargo description	Name	Lat N	Lon E	True Bearing and distance from red light on breakwater	
Vessels carrying grain	FA1	40° 43'.85	014° 26'.74	016°	0.90 Nm
	FA2	40° 43'.88	014° 26'.18	038°	1.09 Nm

Vessels carrying general cargo not dangerous	FB1	40° 44'.30	014° 25'.86	065°	0.95 Nm
	FB2	40° 44'.62	014° 25'.70	084°	1.04 Nm
	FB3	40° 44'.71	014° 26'.00	089°	0.78 Nm

Vessels carrying liquid flammables or combustibles, liquid noxious substances or dangerous products	FC1	40° 44'.33	014° 26'.81	021°	0.42 Nm
	FC2	40° 44'.28	014° 26'.33	049°	0.70 Nm
	FC3	40° 44'.60	014° 26'.42	076°	0.50 Nm