DI.AR. Maritime SRL Naples

MESSINA STRAIT PASSAGE REGULATIONS

Transit is Prohibited

1. To all vessels equal or above **50.000 of G.R.T.** having on board oil cargoes or other noxious goods in bulk, harmful for the marine environment as provided by the International Conventions (transit permitted to ballasted vessels).

Pilotage is Compulsory

- 1. All vessels in transit equal or above 15.000 G.R.T.
- 2. All vessel in transit equal or above **6.000 G.R.T.** having on board oil cargoes or other noxious goods in bulk, harmful for the marine environment as provided by the International conventions.

Pilot Boat Stations

- 1. Ships proceeding Southbound, will board pilot 3 miles North Cape Peloro light and drop him 1,5 miles on the bearing 165° from Punta S. Raineri light.
- 2. Ships proceeding Northbound, will board pilot 2,5 miles SouthEastward Punta Raineri light and drop him 1 mile North Scilla light.

Notices to Port Authorities and Pilots

1. Port Authorities (with copy to Agents) .:

At least 12 hours prior arrival at pilot boat station, the following details must be transmitted either by fax to Number - ++39 0905730832 – or by email "messina@guardiacostiera.it" .:

SHIP'S NAME / FLAG / CALL SIGN / GRT / IMO NUMBER / QUANTITY OF OIL OR OTHER NOXIOUS GOODS ON BOARD (if any) / ETA CAPO PELORO PILOT BOARDING STATION (for ships Southbound), ETA PUNTA SAN RAINERI PILOT BOARDING STATION (for ships Northbound)

Note .: Vessels not subject to compulsory pilotage must communicate by radio the above data directly to Messina and Reggio Calabria Port Authorities at least 2 hours prior the passage.

2. Pilots .:

ETA to be confirmed directly by VHF Channel 16 to Messina Pilot Station at least 1 hour in advance.

Traffic Separation Line

All ships in transit, Northbound or Southbound through the Strait of Messina must keep their starboard side as regard to a traffic separation line joining the following points .:



AA. 38° 16,5' N 15° 43,5' E BB. 38° 14,0' N 15° 36,6' E CC. 38° 10,8' N 15° 36,0' E



General Provisions for the Transit

All ships passing through the Strait of Messina are compelled to observe the following provisions .:

- Keep continuous watch on VHF Channel 16;
- 2. Engine and personnel on Stand-by:
- 3. Make use of radars and / or any other electronic equipment which might be of help in navigation;
- 4. Constant of ship's position for ready communication, on request of the Port Authorities:
- 5. It is compulsory to follow the instructions provided by the International Regulations for Preventing Collision at Sea, 1972.

Messinastrait.doc